



### SPR Details

<b>SPR</b>	1421931
<b>Status</b>	Offen
<b>Priorität</b>	Mittel
<b>Erstellungsdatum</b>	13-Aug-2007
<b>Zuletzt aktualisiert</b>	13-Aug-2007
<b>Abschlussdatum</b>	
<b>Antwort nach Datum</b>	
<b>Beschreibung</b>	Assigning a color to a part using Material Editor doesn't work properly. To reproduce the Issue. 1 Open the Part prt0001.prt 2 Edit# Setup# Material 3 Select the material "CuSn8.mtl" The messsing color is not assigned to the Part As workaround: Customer should assign the color in the Material "Definition Window". Appearance# Default.

### Betroffene Produkte

<b>Produkt</b>	Pro/ENGINEER	
<b>Modul</b>	GLOBAL FUNCTIONS	
<b>Gemeldete Version</b>	Wildfire 3.0	
<b>Gemeldeter Datumcode</b>	M090	
<b>Betroffene Plattformen</b>	All Windows	
<b>Gelöste Version</b>	Wildfire 3.0	Wildfire 4.0
<b>Geplanter Datumcode</b>	Nicht verfügbar	Nicht verfügbar
<b>Gelöster Datumcode</b>	M110	A350

### Verwandte Dokumente

Typ	Nummer	Status	Beschreibung
Call	5738588	Gelöst	Assigning a color to a part using Material Editor doesn't work properly. To reproduce the Issue. 1 Open the Part prt0001.prt 2 Edit# Setup# Material 3 Select the material "CuSn8.mtl" The messsing color is not assigned to the Part As workaround: Customer should assign the color in the Material "Definition Window". Appearance# Default.